Thanks to our patented system, assembling your photobooth is simple. Below are step-by-step instructions to guide you through the process.

Assembly steps

1. Connect pieces 1,2 and 3 together using feet.



3. Next, fit pieces 4,5,6 and 7 making sure the 30mm Velcro is facing the outside of the booth.



5. Fit pieces 15, 16 and 17 into place.



2. Fit a curve (no.28) to the end of piece no.1 and another curve to the opposite end on piece no.3 and attach the two curves together with a foot. Make sure they go on the stickered side.



4. Next, fit piece 9 to connect no's 5 and 6 and then no.8 and no.10.



6. From the top of pieces 4 and 7, connect curves. The four curves are then connected using piece 29.



8. This is followed by fitting pieces 22, 23 and 24.





7.Pieces 18, 19, 20 and 21 are then placed into position.



9. Connect numbers 25 and 26 into their correct positions.

10. One of the 25mm pieces is then fitted on top of beam 25. 28ts are then connected to the top of this piece and also to beam 26. Then the top two curves and the middle two curves are connected by a 29 piece.



11. Beam 27 then fits into place connecting no's 26 and the 25mm piece.





12. From the bottom of piece no 7, connect beam c1. From here fit two curves into position. All of these have feet.

13. Beams B10 and B11 are put into position and are then connected using curves.



15. From the top of B13 and the 25mm piece fit the two 28TB curves. These are then connected to the two middle



14. The four curves are then connected using B12. From the top of B10, B13 is fitted and from the top of B11, B15 is fitted with the remaining 25mm piece. C2 can also be put into its position.



16. Beam C4 and the remaining beam which the curtain goes onto can then be fitted. These have to be put into the blocks simultaneously. Connect the two beams into one side of the booth first but don't twist into position. The beams are then fitted into the opposite side of the doorway making a full connection, they can then be twisted into place.



All done! Your both is now ready to have it's electronics and skins fitted.